

# blast onn.™

**onn. • Roku** Wireless Subwoofer  
Quick Start Guide

Get ready for immersive bass.

# onn. • Roku Wireless Subwoofer



FRONT




Reset  
Power

BACK



Power cable

## What you'll need




To set up, you'll need:

**onn.™ • Roku Smart Soundbar**  
or other compatible Roku audio  
products.

Your Roku remote.

## Setup




### 1. Power up your subwoofer

Place your subwoofer anywhere within 30 feet of your TV.

Plug it into a power outlet.



### 2. Prepare to connect

Go to the home screen and press  on your remote for 5 seconds.

In the setup menu, select subwoofer.


**Note:** If you don't see a subwoofer option, select speaker.



### 3. Follow the on-screen setup

Follow the instructions on your TV screen to connect your subwoofer and test the sound.

## Place wherever you want



Wirelessly connects up to 30 feet  
from your TV.

Need more help  
getting started?

[go.roku.com/  
onnsbwoofer](https://go.roku.com/onnsbwoofer)



Video  
tutorials



Wireless  
help

Find tips, free trials  
and more.

[blog.roku.com](https://blog.roku.com)



**Roku** Blog



© 2019 Walmart Inc. ONN is a trademark of Walmart Inc. All rights reserved.

© 2019 Roku, Inc. All rights reserved. ROKU and the ROKU logo are the registered trademarks of Roku, Inc. All other logos and trademarks herein not owned by Roku, Inc. are the property of their respective owners.



4100000552\_1