



Roku Streaming Stick 4K+

Quick Start Guide

What's included



Roku® Streaming Stick® 4K+



USB power cable
with long-range Wi-Fi® receiver



USB charging cable (for remote)




Remote




Power adaptor

Details



Let's get started

1



STEP 1: Connect your streaming player


Plug the USB power cable into your streaming player. We recommend keeping the power cable coiled in the velcro wrap.

TIP:

For help setting up your device, visit go.roku.com/rss4k

2

Back of TV



OR

Back of TV




STEP 2: Connect to TV

For the best streaming experience, use the included USB power cable and power adaptor to connect your streaming player to a wall outlet.

Or use the included USB power cable to connect to the USB port on your TV.


DOESN'T FIT? Order a free HDMI extender cable at my.roku.com/hdmi



NOTE: See a red light on your streaming player?

That means the USB port on your TV is not providing enough power. Use the included power adaptor instead.

3




STEP 3: Select input

Use your TV remote to power on your TV and select the input (source) you used to connect your streaming player.


4

Back of remote



STEP 4: Pair your remote

Press and hold the pairing button on your remote for 5 seconds until the status light turns green and starts blinking. Your remote will pair automatically.





STEP 5: Follow on-screen setup

Follow the instructions on your TV screen. Activate your streaming player by using your computer or smartphone to link a Roku account.

IMPORTANT:

Roku never charges for activation support.

Remote features



*Headphones sold separately.



Private listening

Plug headphones into your remote to use private listening. Your TV will mute automatically.



Lost remote finder

Say “Hey Roku, where’s my remote?” or use the free Roku mobile app.



Personal shortcuts

Quickly launch a channel, play your favorite playlist, and more in a tap.

To set: Press a personal shortcut button for on-screen instructions.

Just talk to it. It's that easy.



Play entertainment

"Hey Roku, launch The Roku Channel"

"Hey Roku, play classic rock"



Control your streaming

"Hey Roku, pause"

"Hey Roku, turn captions on"



Control your TV

"Hey Roku, turn my TV off"

"Hey Roku, turn it up"



Find more to watch

"Hey Roku, show me the news"

"Hey Roku, search for comedies"

TIP:

For the best experience, keep the remote near you and speak to it when giving a command.

Charging your remote

- Plug the USB charging cable into your remote and any standard USB power adaptor (like your phone charger).
- The status light will stop blinking once your remote is finished charging.
- You'll see a message on your TV when it's time to charge again.

Common questions

Why do I need to create a Roku account?

You'll need a Roku account to stream, add channels, easily manage subscriptions, rent movies, and more.

Why do I need to enter a credit card?

Saving a payment method makes it easy to rent or buy movies, subscribe to popular channels, and start free trials in just a click. No charges will be made without your authorization.

Can I still give voice commands if I turn off hands-free voice?

Yes, you can! Just press and hold the voice button to give a command instead. You don't need to say "Hey Roku" when using push-to-talk voice.

Visit go.roku.com/rss4k for more information

Need more help?

support.roku.com



**Video
tutorials**



**Wi-Fi®
help**

**Cut cable.
Save money.
Stream big.**

streamandsave.com



**Free
TV**



**Live
TV**

**See what's
streaming for free,
tips, and more**

roku.com/blog

Follow us



ROKU

© 2022 Roku, Inc. All rights reserved. Roku, the Roku logo, and STREAMING STICK are the registered trademarks of Roku, Inc. All other logos and trademarks herein not owned by Roku, Inc. are the property of their respective owners.



4100000815_02