



# ROKU<sup>®</sup>

Select Series  
4K TV



## What's included



Roku Select Series 4K TV




65" model x 6 screws



43"/50"/55"/75" models  
x 4 screws

Stand screws



TV stands



Roku TV remote

## What you need



Phillips head  
screwdriver




Laptop or mobile  
phone for activation



Internet connection

## STEP 1: Set up your TV



### **A** Prepare a surface

Put a soft covering like a blanket down onto a clean, flat surface (make sure it's larger than the TV) and place the TV on it.

### **B** Attach the stands


Use a screwdriver and included screws to attach the stands.

### **C** Set TV upright


Place your TV on a stable, flat surface.

## Mounting your TV?

For instructions, skip these steps and visit [go.roku.com/TVmount](https://www.roku.com/TVmount)



## STEP 2: Plug TV in and power your remote



### A Connect your TV


Plug your TV into a power outlet. It should turn on automatically. If it doesn't, press the power button.



### B Power your remote

See the remote features card on how to use your Roku TV remote.

## STEP 3: Activate your TV



### Connect your TV

Follow the instructions on your TV screen. Activate your TV by using your computer or smartphone to link a Roku account.



### IMPORTANT

Roku never charges for activation support.

## Frequently asked questions

---

### Why do I need an internet connection?

You'll need an Internet connection to set up your TV, stream your favourite channels, and for automatic software updates.

### Why should I enter a payment method?

Saving a payment method makes it easy to rent or buy movies, subscribe to popular channels, and start free trials in just a click. No charges will be made without your authorization.

# Get to know your TV

## Video connections

**HDMI** - Game consoles, DVD players

**Antenna/Cable** - Digital antenna, cable connection

## Audio connections



**HDMI eARC (recommended)** - AV receivers, soundbars

**Optical (S/PDIF)** - AV receivers, soundbars

## Other connections

**USB** - Flash drive

**LAN** - Wired internet connection





© 2025 Roku, Inc. All Rights Reserved.  
Roku, the Roku logo and the purple d-pad  
and purple fabric tag designs are  
trademarks or registered trademarks of  
Roku, Inc.

Manufactured under license from Dolby Laboratories.  
Dolby, Dolby Audio, and the double-D symbol are  
registered trademarks of Dolby Laboratories Licensing  
Corporation. Confidential unpublished works. Copyright  
1992-2019 Dolby Laboratories. All rights reserved.

A graphic of a billboard with a white border and a light purple background. At the top, a dark purple rounded rectangle contains the text "Need help?". Below this, the text "For setup or support, visit or call" is followed by the URL "go.roku.com/tv" and the phone number "+1 888-621-0891" with the hours "8:00 am - 10:00 pm PT". A QR code is positioned to the right of the text. The billboard is supported by a white pillar and stands above a stylized city skyline.

## Need help?

For setup or support,  
visit or call

[go.roku.com/tv](https://go.roku.com/tv)

+1 888-621-0891  
8:00 am - 10:00 pm PT

