


5



### STEP 5: On-screen setup and activation

Follow the instructions on  
your TV screen.



Activate your streaming  
player by using your  
computer or smartphone  
to link to a Roku account.

**NOTE:** Roku does not charge for activation support – **beware of scams.**

### Common questions

#### Why do I need to create a Roku account?

Before you can start streaming, channels must be downloaded and installed on your streaming player. You'll need a Roku account to access the Roku Channel Store, manage your subscriptions, view your purchase history, and add a payment method. For more info, visit [go.roku.com/whyaccount](http://go.roku.com/whyaccount)

#### Why do I need to enter a credit card?

Saving a payment method makes it easy to rent or buy movies on demand, subscribe to popular services, and enrol in free trials. Charges will not be made without your authorisation. For more information, visit [go.roku.com/paymenthelp](http://go.roku.com/paymenthelp)

#### What should I do if my streaming player is not connecting to my wireless network?

Your streaming player connects to your wireless network the same as your laptop or smartphone. If these other devices can access the internet, then your streaming player should be able to do the same. Make sure to select the same network name, and enter the same password you use with the other devices. Remember that passwords are case-sensitive and easy to enter incorrectly. For more help, visit [go.roku.com/wireless](http://go.roku.com/wireless)

#### Can I take my Roku streaming player with me when I travel?

Yes. You can bring your streaming player and watch your favourite entertainment when you travel. Remember to also bring a USB power adaptor (like your phone charger), remote, and any cables you use to connect your streaming player at home. Make sure your destination has a good internet connection. You may need a computer or smartphone to help connect your streaming player to a new wireless network. For more details, visit [go.roku.com/travelwithroku](http://go.roku.com/travelwithroku)

#### Need more help getting started?

[go.roku.com/rssplus](http://go.roku.com/rssplus)



Video  
tutorials



Wireless  
help

#### Getting the most out of your Roku streaming player.

[go.roku.com/usingroku](http://go.roku.com/usingroku)



Add  
channels



Mobile  
app

#### Tips, what's streaming for free, and more...

[blog.roku.com](http://blog.roku.com)



Roku Blog



# ROKU® Streaming Stick™+

# ROKU



## Quick Start Guide

### Roku

© 2019 Roku, Inc. All rights reserved. ROKU, ROKU logo and STREAMING STICK are the trademarks or registered trademarks of Roku, Inc. HDMI, the HDMI logo, and High-Definition Multimedia Interface are the trademarks or registered trademarks of HDMI Licensing, LLC. All other logos and trademarks herein not owned by Roku, Inc. are the property of their respective owners.



4100000580\_1

## What's included



Roku® Streaming Stick™+



Power adaptor



USB power extender cable



USB power cable with long-range wireless receiver




Voice remote




Two AAA Duracell® batteries

## Features




## Setup




### STEP 1: Connect to TV

**HDTVs:** Plug your streaming player into an HDMI® port on your TV.

**4K and HDR TVs:** To stream 4K or HDR, choose an HDMI port that supports **HDCP 2.2**. For help determining which port supports HDCP 2.2, visit [go.roku.com/hdcp](http://go.roku.com/hdcp)




**Doesn't fit?** Order a free HDMI extender cable at [my.roku.com/HDMI](http://my.roku.com/HDMI)



### STEP 2: Connect to power


For the best streaming experience, use the included USB power cable, power extender cable and power adaptor to connect your streaming player to a wall outlet.

OR



Alternatively you can use the included USB power cable to power your streaming player from the USB port on your TV.

**NOTE: See a red light on your streaming player?** That means the USB port on your TV is not providing enough power. Use the included power adaptor instead. For help, visit [go.roku.com/lowpower](http://go.roku.com/lowpower)



### STEP 3: Power on TV and select input

Use your TV remote to power on your TV and select the input you used to connect your streaming player.

For help on how to select the correct input, visit [go.roku.com/selectinput](http://go.roku.com/selectinput)



### STEP 4: Insert batteries

On the back side of the remote, slide open the battery cover. Insert included Duracell® batteries placing the negative (-) ends in first.

Your remote should pair with your streaming player automatically. For help pairing your remote, visit [go.roku.com/remotehelp](http://go.roku.com/remotehelp)